

NEW & IMPROVED! CL^{Plus} Non-Oil Transfer Paper

INFORMATION & INSTRUCTIONS

Please Read Instructions Carefully Before Use

Recommended Applications

White or light colored fabrics including 100% cotton, polyester or poly/cotton blends, mouse pads, coasters, binders, etc.

NOTE: NOT RECOMMENDED FOR FABRIC PUZZLES OR CARDSTOCK

Printing Equipment

CL Plus Non-Oil works in Non-Oil Color Laser Copiers and Printers.

General Tips

Remove Sorter

Printing

Fan paper to separate
Feed transfer paper from bypass tray / multi-feed tray.
Copy/Print on the coated side of the transfer paper.
Reduce toner levels by approximately 10% - 20%.
Copy/Print **Mirror Image**.
Copy in **Heavy 1 Mode**. If your printer or copier does not have this setting or you are unsure which mode to use please call for further information.

Transfer with Heat Press

Trim away the unprinted paper around your image with scissors/exacto knife.
Position the imaged sheet with printed side face down.

- **Press at 385-400°F (195°-205C) using Maximum pressure for 25-30 seconds.**
- **Wait 5-10 seconds before peeling. Peel backing paper off, slowly while warm.**
- **Pull fabric on its ends before peeling for easier peel.**

Washing Instructions

Always turn textile inside out before washing.
Recommended: Machine wash in cold water.
Optional: Machine wash in warm water (40°C).
Use mild detergent. Do not use harsh or bleaching materials.
Recommended: Hang dry
Optional: Tumble dry with cool or warm air setting. Do not use fabric softeners.
After washing we recommend turning shirt inside out and ironing the image from the back.
Do not Dry Clean